

Rev. 07/09/10

Overview

Some automation providers use the smaller RJ22 (telephone handset connector) instead of the RJ11 (telephone wall connector) for their in-the-zone network communications devices. The BAPI RJ22 Communications Adapter converts the standard RJ11 jack used in BAPI sensors to the smaller RJ22 dimensions.


ORDERING INFORMATION

Part Number	Description
BA/RJ22	Communications Adaptor
BA/RJ22L	Communications Connector


See end of Section E for list pricing.



RJ22

Communications
Adaptor

RJ11 Connector

RJ22L Connector
(RJ11 with RJ22
Adaptor)

Spanner Security Screws & Spanner Bit


Overview

Spanner Security Screws add an extra level of protection for Wall Plate Units. The Security Screws and associated Spanner Bit are available for any Stainless Steel Wall Plate Unit.

ORDERING INFORMATION

Part Number	Description
BA/SP632x1	Spanner Security Screws, 6-32x1" (box 50)
BA/SPBIT	Spanner Bit for Spanner Security Screws

See end of Section E for list pricing.



Spanner Security Screws



Spanner Bit

Hex Head & Pan Head Screws & Wall Anchors

Overview

These 1.5" stainless steel #10 screws and nylon wall mounting anchors are used to attach the BAPI-Box or BAPI-Guards to the wall. The Pan Head Screws and Anchors are used for drywall. The Pan Head Screws alone can be used for sheet metal or wood surfaces. The Hex Head Concrete Screws and Anchors are used for concrete walls. The screws and anchors are sold in packs of 100.

ORDERING INFORMATION

Part #: BA/Screw-Pan-1.5x10-SS-100

1.5" Stainless Steel #10 Pan Head Screw, Pack of 100

Part #: BA/Screw-Hex-Concrete-1.5x10-SS-100

1.5" Stainless Steel #10 Hex Head Concrete Screw, Pack of 100

Part #: BA/Anchor-10-100

1.36" Nylon Anchor for #10 Screws, Pack of 100

See end of Section E for list pricing.



Pan Head Screws



Hex Head Screws

Wall
Mounting
Anchors